

**3032E Compact Utility Tractor**  
LV317050 A.2



LV317050

*(Specifications and design subject to change without notice)*

**To The Customer**

The part numbers in this Parts Catalog were correct at the time of publication. Per John Deere policy, we continuously improve our products. Therefore, when ordering parts verify the part numbers with your dealer.

**SI Units of Measure**

Metric dimensions are provided as applicable throughout this parts catalog.

**Bolt and Cap Screw Strength Identification**

Bolts and cap screws required to have high-strength qualities equivalent to metric property class 10.9 (SAE grade 8) or higher are identified throughout this catalog by the description 10.9, 12.9 or 14.9. All standard bolts and cap screws are metric property class 8.8 (SAE grade 5) or lower.

**Serial Number Listing Information**

Serial number information is listed to show on which machines each part can be used; for example:

- The part can be used on all products.
- 000000 – The part can be used on products beginning with the serial number listed.
- 000000 The part can be used on products up to and including the serial number listed.
- 000000 – 000000 The part can be used on products between and including the serial number listed.

When XXXXXX's are listed in place of a serial number, a serial number change was made, but the exact serial number was not available at the time of publication.

**Illustrations**

Illustrations in this catalog are only intended as a reference for dealers and customers. These illustrations do not necessarily represent the exact view of the parts.

**Box-Enclosed Illustrations**

Box-enclosed keyed parts in the illustration are available as a service assembly or an attachment. These parts may also include parts not available for service. The illustrations may not show all individual parts of an attachment. A box not keyed includes non-current parts.

**Orientation Of Product**

An arrow shown with an illustration is to indicate the direction of product forward travel. Right Hand (RH) and Left Hand (LH) sides are determined by product forward travel.

**Orientation of Engine**

Right Hand (RH) and Left Hand (LH) sides are determined by standing at flywheel and facing the engine.

### John Deere Remanufactured Components

The REMAN parts listed in this catalog are intended for the repair or replacement of failed or worn original equipment components. John Deere Reman components are manufactured to stringent John Deere standards and produced to original John Deere specifications that incorporates the latest design and performance improvement updates.

#### Ag and Turf Tractor — Trademarks

ACST <sup>™</sup>	GreenStar <sup>™</sup>	PowrQuad <sup>™</sup>
ActiveSeat <sup>™</sup>	Harvest Smart <sup>™</sup>	PowrReverser <sup>™</sup>
AirCushion <sup>™</sup>	HarvestLab <sup>™</sup>	PowrSync <sup>™</sup>
AutoPowr <sup>™</sup>	HillMaster <sup>™</sup>	ProDrive <sup>™</sup>
AutoQuad <sup>™</sup>	HydraFlex <sup>™</sup>	QuikTach <sup>™</sup>
AutoTrac <sup>™</sup>	iMatch <sup>™</sup>	Reman <sup>™</sup>
Bullet Rotor <sup>™</sup>	iTorque <sup>™</sup>	Roll-Gard <sup>™</sup>
ClimaTrak <sup>™</sup>	IVLOC <sup>™</sup>	Service ADVISOR <sup>™</sup>
ComfortCommand <sup>™</sup>	IVT <sup>™</sup>	StarFire <sup>™</sup>
ComfortGard <sup>™</sup>	JDLink <sup>™</sup>	StellarSupport <sup>™</sup>
CommandARM <sup>™</sup>	Load Command <sup>™</sup>	STS <sup>™</sup>
CommandCenter <sup>™</sup>	Mega Track <sup>™</sup>	SyncReverser <sup>™</sup>
CommandTouch <sup>™</sup>	Nothing Runs Like a Deere <sup>™</sup>	SyncroPlus <sup>™</sup>
CommandView <sup>™</sup>	Parallel Tracking <sup>™</sup>	SyncShift <sup>™</sup>
Contour-Master <sup>™</sup>	PermaClutch 2 <sup>™</sup>	SyncShuttle <sup>™</sup>
COOL-GARD <sup>™</sup>	Phoenix <sup>™</sup>	TLS <sup>™</sup> (Triple-Link Suspension)
Field Office <sup>™</sup>	Power Zero <sup>™</sup>	TMIII <sup>™</sup>
FieldCruise <sup>™</sup>	PowerGard <sup>™</sup>	TMII <sup>™</sup>
Funk <sup>™</sup>	PowerTech <sup>™</sup>	Vari-Cool <sup>™</sup>

## Ag and Turf Tractor — Terms and Abbreviations

Phrase	Meaning	Phrase	Meaning
2WD	Two Wheel Drive	NA	Not Applicable
4WD	Four Wheel Drive	OD	Outside Diameter
A/C	Air Conditioning	OOS	Open Operator's Station
AH	Ampere-hour	OPTION	Option
ALSO ORDER	Also Order	OR	Or
AND	And	ORDER	Order
APPL	This Application Only	ORDER WITH	Order With
AR	As Required	OS	Oversize
CAC	Charge Air Cooler	PC-HYDRAULICS	Pressure Compensated Hydraulics
CTL	Cut To Length	PFC-HYDRAULICS	Pressure and Flow Compensated Hydraulics
DEF	Diesel Exhaust Fluid	PKG	Package of
ECU	Engine Control Unit	PST	Power Shift Transmission
EGR	Exhaust Gas Recirculation	PTO	Power Take-Off
FOR	For	REAR	Rear
FRONT	Front	REMAN	Remanufactured
FT4	Final Tier 4 / Stage-IV	RH	Right Hand
HCS	Hydraulic Cab Suspension	ROPS	Roll Over Protection Structure
HI-LO	High-Low	SCR	Selective Catalytic Reduction
HMS	Headland Management System	SCV	Selective Control Valve
HVAC	Heating, Ventilation and Air Conditioning	SFA	Front Axle Suspension Control Unit and/Or Cab Suspension Unit
ICV	Independent Control Valve	SSU	Control Unit for Steering System (AutoTrac™)
ID	Inside Diameter	STD	Standard
INCLUDES	Includes	SUB FOR	Substitute For
Phrase	Meaning	Phrase	Meaning
IT4	Interim Tier 4 / Stage-IIIb	T2	Tier 2 / Stage-II
KIT	Kit	T3	Tier 3 / Stage-IIIa
LGTH	Length	TCU	Transmission Control Unit
LH	Left Hand	TK	Thickness
LS	Load Sensing	UP	Upper
LTC	Low Temperature Circuit	USE WITH	Use With
MARKED	Marked	W/	With
MF	Make From	W/O	Without
MFWD	Mechanical Front Wheel Drive	Z	Gear and Sprocket Teeth Number

**Product Identification Number, 17-Digit**

An individual product identification and serial number is assigned to each machine. When writing about or filling out warranty claims, use all the characters shown on the plate.

LV543325 A.1

1
2
3
4
5
6
7
8
9
10

\* 1
LV
3
032
E
+
N
P
1
00000\*

LV543325

1 - Tractor World Manufacturing Code	1
2 - Tractor Manufacturer	LV - John Deere Augusta Works
3 - Tractor Series	3
4 - Tractor Engine HP	032
5 - Tractor Family	E
6 - Check Letter	+
7 - Calender Year	N - 2022
8 - Tractor Model Year	P - 2023
9 - Platform Identifier	1 - Open Operator's Station ( R4 )
10 - Tractor Serial Number	00000

3032E Compact Utility Tractor

Calendar Year / Model Year

Year	Code	Year	Code	Year	Code	Year	Code
2008	8	2018	J	2028	W	2038	8
2009	9	2019	K	2029	X	2039	9
2010	A	2020	L	2030	Y	2040	A
2011	B	2021	M	2031	1	2041	B
2012	C	2022	N	2032	2	2042	C
2013	D	2023	P	2033	3	2043	D
2014	E	2024	R	2034	4	2044	E
2015	F	2025	S	2035	5	2045	F
2016	G	2026	T	2036	6	2046	G
2017	H	2027	V	2037	7	2047	H